

# CT1D Series CT1D CO2 Temp Duct Sensor

- Optional LCD display with field calibration menu
- Adjustable for ranges of 2000, 5000, or 10,000 ppm CO2
- Integrated set-point relay
- Field replaceable NDIR element













#### **DESCRIPTION**


Self-calibrating NDIR sensor for high accuracy. An optional built-in LCD display makes set up a snap, and a standard solid-state setpoint relay makes demand ventilation easy. Probe is non-directional for accurate readings and ease of installation. Dual 4-20mA and 0-10/5 vdc outputs.

#### **APPLICATIONS**

- Controlling ventilation in response to occupancy
- Facilitates compliance with ASHRAE 62.1 standard for air quality
- Offices, conference rooms, and public assembly areas









Made in the USA - 7-year Warranty

## Field replaceable CO2 element for lower total lifetime cost

#### **FEATURES**

- Integrated display and push-button menus for field selectable scale, calibration, and operational modes
- Dual 4-20mA and 0-5V/0-10V output (jumper selectable)
- Integrated high-reliability solid-state set-point relay is ideal for direct control applications; easy to set up thanks to LCD
- · Non-dispersive infrared sensing element (NDIR)

- Field replaceable CO2 sensor
- 15+ year life expectancy on CO2 sensing element
- Industry leading 7-year limited warranty on electronics; NDIR module 3 years
- Selectable auto-calibration mode returns sensor to baseline values
- ±30ppm, ±3% of reading



#### **ORDERING**

CT1

**Enclosure** 

D

D= Duct H = Hose Barb

A= None

Temperature

B=Transmitter\* C= 100PtRTD D= 1000PtRTD

E= 10KType 2 F= 10KType 3 G= 10K W/ 11K

H=3KI = 2K2J = 1K8K = 20KL = 100K 3

Display Output X= None 3 = 4 - 20 mA,

> 0-5V, 0-10V D=Display 3-Wire Connection

**Dual Channel** 

Blank = NDIR D = Dual Channel

#### **Replacement Sensors:**

AQS - CO2 AQS - D CO2


Replacement CO2 Sensor


Replacement Dual CO2 Sensor

<sup>\*</sup> Order B=transmitter to display temperature reading; thermistor and RTD options will not display temperature on LCD



### DIMENSIONS







**Warning:** The datasheet is designed for reference only. Refer to installation instructions that accompany the product and heed all safety instructions. Product improvement is a continuing process at Senva. Changes may occur to products without prior notice.



SPECIFICATIONS		
Power Supply		12-30VDC/24VAC(1), 100mA max.
Analog Outputs	Dual Analog Output scaling	3-wire 4-20mA and 0-5V/0-10V (2) (jumper) 0 - 2000 or 0 - 5000 ppm (selectable)
Set-point Relay	Programmable	Solid-state, 1A @ 30VAC/DC, N.O.
Sensor Performance	Type Accuracy (Standard)	Non-dispersive Infrared (NDIR) ±30ppm, ±3% of reading (400-2000ppm), @-10-50°C, 0-85%RH
		±50ppm, ±5% of reading (2000-5000ppm), @-10-50°C, 0-85%RH
		±100ppm, ±10% of reading (5000-10000ppm), @ 0-50°C, 0-85%RH
	Accuracy (Dual Channel)	±30ppm, ±3% of reading (400-2000ppm), @ 0-50°C, 0-85%RH
		±50ppm, ±3% of reading (2000-5000ppm), @-10-50°C, 0-85%RH
		±100ppm, ±10% of reading (5000-10000ppm), @ 0-50°C, 0-85%RH
	Drift with ABC disabled (standard)	35 ppm/month
	Drift with ABC disabled (Dual Channel	) 5 ppm/month
	Pressure Dependency	+1% reading per kPa (0.143PSI) deviation from nominal (101kPa,14.7PSI)
	Response time	60 seconds to 90% reading
	Sample rate	1 second
	Output update rate	1 second
	Element Operating Environment	4 to 122°F (-20 to 50°C), 0 to 95% RH
LCD Menu Setup Parameters	SPH, Setpoint, Hi (On point)	500ppm to full-scale (800ppm default)
	SPL, Setpoint, Lo (Off point)	400ppm to full-scale-50 (700ppm default)
	SCL, Scaling	0-2000ppm, 0-5000ppm, 0-10000ppm (2000ppm default)
	ADJ, Adjustment	Offset adjustment +/-250ppm (0 default)
	CAL, Calibration mode	Automatic mode ON or OFF (default=ON)
	RUN, Run mode	Displays CO2 in ppm
Operating Environment	Temperature	14 to 122F (-10 to 50C)
	Humidity	0-95% non-condensing
Enclosure	Material	ABS/Polycarbonate
	Dimensions	4.0' h x 4.4"w x 2.1"d (+6.8" probe)

- 1. One side of transformer secondary is connected to signal common. Dedicated transformer is recommended.
- 2. 15-30VDC/24VAC power supply voltage required for 10 volt output.
- 3. Operating outside of element operating environment may result in reduced accuracy.
- 4. Time for reaching 63% of reading at 25oC and 1 m/s airflow.
- 5. It is not recommended to de-activate ABC (auto-calibration) except for continously occupied spaces or greenhouses. Drift ratings may vary based on environment

<sup>\*</sup> Product improvement is a continual process at Senva and product features and specification may change without prior notice. Refer to instructions that accompany the product for installation and wiring.